

### **Fitting Instructions for Suffolk**

1. Find centre of door opening and measure out position for the support brackets, this can vary as long as they fit under the base ends.
2. Fix the brackets level onto the wall using plugs, screws, and cover caps provided.
3. Position onto brackets and centralise with the door opening.
4. Drill the upstand at 300mm centres and plug & screw to the wall, using screws & cover caps. Fix end of each bracket into tray.
5. Clean off any dust or dirt and seal using suitable silicone sealant.
6. Your installation is now completed.

Your canopy will give years of maintenance free service and requires only the occasional wash with warm soapy water.

***NB Do not use abrasive or solvent cleaners on this product.***