

Fitting instructions for Berkeley overdoor canopies

Brackets

1. Position brackets at each side of door opening, ensuring that they are level and at the correct distance apart.
2. Drill a hole at the bottom of the bracket just under where the 2 pieces meet. This is to ensure that the screw passes through the timber block.
3. Drill a second hole near the top of the bracket, below the horizontal section.
4. Position bracket and mark wall for drilling. Drill & plug hole in wall.
5. Fasten brackets to wall using screws and cover caps provided.

Base section

1. Drill flange at back of base at approximately 400mm centres, and also the flange at back of the base uprights. Lift base onto brackets and centralise.
2. Mark holes on wall, lift base unit down, and drill & plug wall. Fix base unit back in position.
3. Screw up through bracket into timber insert in base to secure unit to brackets.

Top section

1. On the simulated lead flashing upstand, mark holes at 400mm centres, starting 50mm from each end, Drill through upstand.
2. Slide top section onto base unit, and mark holes on wall. Lift down top section.
3. Drill & plug holes in wall, fit top section and fasten with screws and caps.
4. Run a bead of clear silicone along the top of the lead effect flashing to prevent water ingress.
5. Wash down your Berkeley canopy with warm soapy water.

Your canopy will give years of maintenance free service, and will require only an occasional wash with warm soapy water.

NB Do not use abrasive or solvent cleaners on this canopy. Doing so will invalidate warranty.