

### **Fitting Instructions for Balmoral**

1. Find centre of door opening and measure out position for the support brackets, this can vary as long as they fit under the base ends.
2. Fix the brackets level onto the wall using screws plugs and cover caps provided.
3. Position bottom tray onto brackets and centralise with the door opening, screw back against wall and fix end of each bracket into tray.
4. Slide top section onto secured bottom tray and fix back to wall through the lead look upstand at approximately 300mm intervals.
5. Additional screws & coloured caps may be fitted around the front edge to hold the front faces of the top & bottom sections together.
6. Clean off and dust or dirt and seal using suitable silicon sealant.
7. Your installation is now completed.

(N.B. The Balmoral canopy can be installed without brackets go straight to paragraph 3 in this instance and support base with temporary batten until fastened.)

#### **Items needed (supplied in fixing kit)**

2 x 3" screws

2 x 4" screws

6 x 2" screws

10 x rawlplugs

10 x screw cover caps

2 x tubes silicone (not supplied)